



ANVÄNDARMANUAL OCH INSTALLATIONSANVISNINGAR

för Profsafe Värdeskåp EN 1143-1:2005, Grade I (lättvikt)

PROF-SERIEN

(For English please see page 5)



	<u>Innehållsförteckning:</u>	<u>Sida:</u>
1.)	Introduktion	2
2.)	Transport och emballage	2
3.)	Instruktion för hantering och fastmontering i golvet	2
4.)	Instruktioner för FAS 6580 - omställbart nyckellås	2
5.)	Dekkelplåt insidan av dörren	3
6.)	Löpande underhåll och kontroll	3
7.)	Garanti	3
8.)	Snabbguide elkodlås PIVOT BOLT	4



1. Introduktion

Värdeskåpet är testat och certifierat enligt EN 1143-1. Som standard är skåpet utrustat med ett omställbart nyckellås FAS 6580 (2 fasta nycklar). Som tillval finns delbara nycklar.

Skåpen är förberedda för montage av elkodlås.

2. Transport och emballage

Värdeskåpet transporteras stående på en lastpall. Skåpet är förankrat i pallen via en bult i botten av skåpet. Skåpets hörn är skyddade mot stötar och hela skåpet är packat i polyetenplast.

Om inte annat överenskommits, placeras de båda nycklarna vid skåpets handtag. Förvissa er omgående att båda nycklarna finns där (innan emballaget bortforslas - reklamationer för eventuellt saknade nycklar accepteras inte i efterhand.) Kontrollera också omedelbart att inga transportskador finns (eventuella transportskador måste ovillkorligen anmälas skriftligen till transportbolaget – med kopia till det företag ni köpt skåpet av – i direkt anslutning till mottagandet av skåpet) Innan skåpet ställs på tilltänkt plats, tänk på att kontrollera bärigheten och eventuella hinder på transportvägen.

3. Instruktion för hantering och fastmontering i golvet

För din säkerhet och i enlighet med bestämmelser ska värdeskåp som väger under 1000 kg alltid fästas i golvet på ett tillförlitligt sätt. Säkerställ alltid först både golvet bärighet samt att inget i golvet skadas vid håltagningen.

Skåpet är förberett för fastsättning i golvet med 4 hål. Borra hål diam.10 mm och minst 100 mm djupt.

4. Instruktioner för FAS 6580 – omställbart nyckellås

För att högsta säkerhet skall uppnås bör följande iakttas:

- Nyckeln bör alltid efter användning (även upplåsning) tas ur låset så att den ej är tillgänglig för obehöriga.
- Förvara alltid nyckeln på ett säkert ställe.
- Vid förlust av nyckel bör låset snarast ställas om till ny låsning.

Viktigt: Läs igenom hela instruktionen innan du börjar omställningen. Omställning skall alltid göras med öppen dörr. Bruka aldrig våld!

Omställning till ny nyckel:


- Öppna dörren och lås ut regelverket med handtaget. Vrid nyckeln moturs tills det tar stopp, dvs som man normalt låser låset.
- Öppna dekkelplåten på dörrens insida
- Tryck in knappen på låsets baksida med en penna eller en smal mejsel och håll den intryckt. Gamla nyckeln ska sitta i låset.
- Vrid nyckeln medurs tills det tar stopp, släpp knappen och ta ur nyckeln.
- Sätt in den nya nyckeln och vrid den till låst läge. Låset är nu inställt efter den nya nyckeln.

OBS : Testa alltid med öppen dörr.




8. Snabbguide elkodlås PIVOT BOLT

OBS! Vid frekventa öppningar dagligen bör koden på kodlåset bytas minst en gång per år för att minska slitage på knappsatsen.

Nedan visar symbolen  det antal signaler du hör





Ändra kod

22*(befintlig kod)# 
(Ny kod)# 
(Ny kod)# 

Lägga till användarkoder

OBS! Huvud- eller gruppkod krävs för denna programmering
74*(Huvud- eller gruppkod)# 
(PIN-position 2-9)# 
(Ny användarkod)# 
(Ny användarkod)# 

Radera koder

OBS! Huvud- eller gruppkod krävs för denna programmering
74*(Huvud- eller gruppkod)# 
(PIN-position som skall raderas)# 



Byte av batteri

Dra den fjäderbelastade knappen (kl. 12 på knappsatsen) mot dig och vrid försiktigt knappsatsens ring motsols tills det tar stopp. Dra ringen försiktigt mot dig och batteriutrymmet blir synligt.

Sifta batteri. Duracell 9V alkaliska rekommenderas.

Säkerställ att inga kablar ligger i kläm, tryck sedan tillbaka ringen mot monteringsplattan och vrid ringen medsols till sitt ursprungsläge. Knappen skall nu snäppa tillbaka.

Kontrollera låsets funktion minst 3 gånger innan skåpdörren stängs.

Övrig programmering

Se "Programmeringsguide Sargent & Greenleaf Titan Pivot Bolt/Titan Direct Drive & 6124/6125"





Page:

1.)	Introduction	5
2.)	Transporting	5
3.)	Instruction for handling and anchoring to floor	6
4.)	Lock instruction S&G 6580 - changeable keylock	6
5.)	Cover inside of the door	6
6.)	Maintenance and control	7
7.)	Warranty	7
8.)	Quickguide digital lock PIVOT BOLT	7



1. Introduction

The safe is tested and certified according to EN 1143-1.
As standard the safe is fitted with S&G 6580 changeable key lock (two keys)
As accessories there are detachable keys available. The safes are prepared to take digital locks.



2. Transporting

The eurograde safe is transported fixed on a pallet. Corners etc. are protected and the safe is wrapped in transparent plastic.

If not anything else is agreed the two keys are placed by the handle. Please make sure that the two keys are there (before you take away the packing – any claims for lost keys are not accepted afterwards). Please also control that there are no transportdamages (any transportdamages must immediately be reported to the transport company in writing, with a copy to the company from whom you bought the safe).



Before you place the safe on its definite place you ought to control carrying capacity of the floor and you also ought to control that there are no blocking objects in the way.



3. Instruction for handling and anchoring to floor

For your security and in accordance with certification the safes lighter than 1000 kg should always be fixed to the floor.

Always ensure that the floor can take the weight of the safe and that nothing in the floor can get damaged during fixing of the safe.

The safe is prepared for anchoring in the base with four holes. Drill holes diam. 10 mm and with at least 100 mm depth.



4. Lock instruction S&G 6580 – changeable key lock

Read instruction before starting the changing procedure.

Key changing function should always be made with the safe door open.

The key must always be taken away from the lock after use in order to avoid unauthorized use.

Always keep the key in a safe place.

In the event of key loss, lock must be re-set with new key as soon as possible in order to maintain maximum security.

Change procedure:

- Open the door fully, with the door open throw the bolt work to the fully closed position.
- Open the lock cover on the inside of the door.
- Depress the change button on the back of the lock body.
- While holding down the button turn key until bolt is fully retracted, i.e. lock open.
- When bolt is fully retracted, remove key and release pressure on the button.
- Insert new key and turn key until bolt is fully extended i.e. lock closed.
- Turn key several times to the locked unlocked position to ensure that change has been effected correctly. Shut the door, secure and remove key.

Additional locks are:

Digital locks

S&G PIVOT BOLT (rotary bolt)

S&G 6125F (dead bolt)

S&G 6127 (dead bolt)

Kaba Mas auditcon 3100 series (dead bolt)

La Gard 39E (rotary bolt)

La Gard LG Audit 66E (rotary bolt)



5. Cover inside of the door

Inside of the cover plate inside the door you find the locking mechanism and the lock.

Note that access inside the cover plate is only allowed for authorized person.

Access by non-authorized person may result in that both certificate and warranty are no longer valid.





6. Maintenance and control

Annual maintenance should be carried out on the eurograde safe to ensure trouble-free usage:

- Checking function of the lock
- Checking function and smooth movement of the locking bolt.
- If necessary greasing of the hinges
- If necessary greasing of the moving parts in the locking mechanism but not the lock itself.
- Checking the steel wire for the re-locker.

NOTE: Never grease any lock!

Allow only authorized person to work with the lock and the locking mechanism.



7. Warranty

The safe has 12 months warranty against manufacturing defects from date of delivery, provided this manual is followed completely.

Warranty on locks are 12 months but only includes exchange of false components.

Any working cost for access to the lock is not included in the warranty. Any claim must unconditionally be reported in writing. Any transport damage must be reported to the driver immediately when the safe is received. If this is not the case, these type of damages are not possible to regulate later on.

If a cabinet has been exposed to burglary or a burglary attempt the EN 1143-1 certificate is no longer valid and the certificate sign shall be removed.



8. Quick guide digital lock PIVOT BOLT

Please note! When frequent daily openings of the safe the code shall be exchanged at least once a year to minimize wear of the keypad.

The ! symbols in examples show the number of beeps you hear.

Always wait for each set of beeps to end before entering another number or letter, or you will interrupt the code sequence.



Changing Your Own Code or the Factory Default Code

2 2 * YOUR OLD CODE # (!!!!) NEW CODE # (!!!) NEW CODE # (!!!)

Creating a New Code (Supervisor or User Code)

7 4 * MASTER CODE OR SUPERVISOR CODE # (!!!!) PIN POSITION # (!!!)
NEW CODE # (!!!) NEW CODE # (!!!)

Deleting a Code (Supervisor or User Code)

7 4 * MASTER CODE OR SUPERVISOR CODE # (!!!!) PIN POSITION # (!!!) # (!!!) # (!
!!)

Change battery

Pull the keypad tab out slightly and turn the keypad ring counterclockwise.

The ring will pull out from the base far enough to reveal the battery compartment.

Remove the battery from the connector.

Attach the new battery and place it in the battery compartment.

Push the keypad ring back against the base and turn it clockwise until it clicks into place.

Test the lock function at least three times with the door open before closing the safe.

